

Installation instructions: 6" polycarbonate track

 \bigcirc

Nyloc Nut: When installing in an area that does allow access to the backside of the mounting surface. Well Nut: when installing when there is no access to the backside of the mounting surface.



